






ASSEMBLING INSTRUCTION



Type : CIREBON DINING TABLE
Art.No : 18002-679




TIME	LABOUR	TOOLS
 20'	 1	 2
		

CIREBON DINING TABLE		
PARTLIST		
No.	Description	Qty.
1	88888-144 SP CIREBON DINING TABLE - LEGS	2
2	PALANGAN ASSY	2
3	TOP TABLE	1


CIREBON DINING TABLE		
88888-142 SP SCREW SET		
No.	Description	Qty.
A	JCBC M6 x 15 mm	8
B	JCBC M6 x 35 mm	8
C	WASHER M6	8
D	SCREW Ø10 x 1½" PAB	8
E	SCREW Ø10 x 2½" PAB	6
F	PEN DUPLO Ø5	5
G	M4 ALLEN KEY	1

CIREBON DINING TABLE		
88888-143 SP PLASTIC FEET		
No.	Description	Qty.
H	NYLON FOOT CAP	4


ILLUSTRATION :

A	B	C	D
			
E	F	G	H
			



STEP-1



STEP-2



STEP-3



FULL-ASSEMBLY