

### GARDEXA GATE AND ACCESSORIES INSTALLATION INSTRUCTIONS

ART. NUMBER: FG020985 / SINGLE GATE SET H90\*W100CM

- 1. Determine the location of the gate(a).
- 2. Install the gate handles and lock(c). the lock cylinder is adapted to the two holes of the square bars, then secure with screws.
- 3. Mount the door to the steel posts w/Build-in Nut that you buy from Gardexa and secure with hinges (b).
- 4. Install the lock stop(d) to correct position according to the position of the lock, and then secure with self-tapping screws.
- 5. Mount the lock stop sheet(e) to the lock stop.









ART. NUMBER: FG020984 / DOUBLE GATE SET H90\*W300CM

- 1 Determine the location of the gate.
- 2 Mount the door to the steel posts w/Build-in Nut that you buy from Gardexa and secure with hinges (b).
- (3) Install the gate handles and lock (c). the lock cylinder is adapted to the two holes of the square bars, then secure with screws.
- 4 Install the gate bolts (d) to the gate. According to the position of the bolts (d), set the gate stop (e) into the ground.








### GARDEXA GATE AND ACCESSORIES INSTALLATION INSTRUCTIONS

ART. NUMBER: FG020983 / SINGLE GATE SET H120\*W100CM

- 1. Determine the location of the gate(a).
- 2. Install the gate handles and lock(c). the lock cylinder is adapted to the two holes of the square bars, then secure with screws.
- 3. Mount the door to the steel posts w/Build-in Nut that you buy from Gardexa and secure with hinges (b).
- Install the lock stop(d) to correct position according to the position of the lock, and then secure with self-tapping screws.
- 5. Mount the lock stop sheet(e) to the lock stop.









ART. NUMBER: FG020982 / DOUBLE GATE SET H120\*W300CM

- 1 Determine the location of the gate.
- 2 Mount the door to the steel posts w/Build-in Nut that you buy from Gardexa and secure with hinges (b).
- (3) Install the gate handles and lock (c). the lock cylinder is adapted to the two holes of the square bars, then secure with screws.
- 4 Install the gate bolts (d) to the gate. According to the position of the bolts (d), set the gate stop (e) into the ground.







### GARDEXA GATE AND ACCESSORIES INSTALLATION INSTRUCTIONS

ART. NUMBER: FG020979 / CURVE SINGLE GATE SET H120\*W100CM

- 1. Determine the location of the gate(a).
- 2. Install the gate handles and lock(c). the lock cylinder is adapted to the two holes of the square bars, then secure with screws.
- 3. Mount the door to the steel posts w/Build-in Nut that you buy from Gardexa and secure with hinges (b).
- 4. Install the lock stop(d) to correct position according to the position of the lock, and then secure with self-tapping screws.
- 5. Mount the lock stop sheet(e) to the lock stop.








ART. NUMBER: FG020978/ DOUBLE CURVE GATE SET H120\*W300CM

- 1 Determine the location of the gate.
- 2 Mount the door to the steel posts w/Build-in Nut that you buy from Gardexa and secure with hinges (b).
- (3) Install the gate handles and lock (c). the lock cylinder is adapted to the two holes of the square bars, then secure with screws.
- 4 Install the gate bolts (d) to the gate. According to the position of the bolts (d), set the gate stop (e) into the ground.






ART. NUMBER: FG020977/ DOUBLE CURVE GATE SET H120\*W400CM

- ① Determine the location of the gate.
- 2 Mount the door to the steel posts w/Build-in Nut that you buy from Gardexa and secure with hinges (b).
- (3) Install the gate handles and lock (c). the lock cylinder is adapted to the two holes of the square bars, then secure with screws.
- 4 Install the gate bolts (d) to the gate. According to the position of the bolts (d), set the gate stop (e) into the ground.





ART. NUMBER: FG020976/ DOUBLE CURVE GATE SET H150\*W400CM

- ① Determine the location of the gate.
- 2 Mount the door to the steel posts w/Build-in Nut that you buy from Gardexa and secure with hinges (b).
- (3) Install the gate handles and lock (c). the lock cylinder is adapted to the two holes of the square bars, then secure with screws.
- 4 Install the gate bolts (d) to the gate. According to the position of the bolts (d), set the gate stop (e) into the ground.

